



FIG.1




Ref No	Part No	Description
1	11401-02890	Gasket Set
2	11141-02H00	. Gasket, Cylinder Head
3	11173-01H00	. Gasket, Cylinder Head Cover No.1
4	11178-01H00	. Gasket, Cylinder Head Cover No.2
5	11191-27E00	. Washer, Head Cover
6	11482-01H00	. Gasket, Clutch Cover
7	11483-01H00	. Gasket, Generator Cover
8	11484-01H00	. Gasket, Breather Cover
9	11489-01H00	. Gasket, Oil Pan
10	12837-02H00	. Gasket, Tensioner Adjuster
11	14181-46E00	. Gasket, Exhaust Pipe
12	09280-15007	. O Ring, Oil Pump
13	09280-17003	. O Ring, Oil Filler Plug
14	09280-25004	. O Ring, Oil Strainer
15	09280-33004	. O Ring, Crankshaft Hole Plug
16	09280-71008	. O Ring, Starter Gear Cover

**FIG.2**



Ref No	Part No	Description
1	11171-01H00	Cover, Cylinder Head
2	11173-01H00	Gasket, Head Cover No.1
3	11178-01H00	Gasket, Head Cover No.2
4	11179-37H00	Shield, Head Cover
5	09106-07021	Bolt (7x17.5)
6	11191-27E00	Washer


**FIG.3**



Ref No	Part No	Description
1	11100-38H00	Head Assy, Cylinder
2	09103-06266	• Bolt
3	09206-08007	• Pin
4	09168-06018	Washer
5	11115-29G70	Guide, Valve (os 0.5)
6	11141-02H00	Gasket, Cylinder Head
7	04211-11169	Pin
8	11117-29G00	Bolt (10x95)
9	09103-06222	Bolt, Oil Gallery
10	09168-06023	Gasket
11	07120-0650A	Bolt, Cylinder Head
12	11179-81402	O Ring, Spark Plug Pipe
13	09280-11001	O Ring
14	09493-80005	Jet, Oil
15	09280-04004	O Ring
16	09248-16012	Plug
17	09168-16009	Gasket
18	09482-00558	Spark Plug (ngk,cr9eia-9)
18	09482-00557	Spark Plug (denso,iu27d)
18	09482-00556	Spark Plug (ngk,cr8eia-9)
18	09482-00560	Spark Plug (ngk,cr10eia-9)
18	09482-00555	Spark Plug (denso,iu24d)
18	09482-00559	Spark Plug (denso,iu31d)
19	13101-38H00	Pipe, Intake
20	09280-46006	• O Ring (d:2.40,id:47.0)
21	13826-02H12	Clamp, Intake Pipe
22	09120-06007	Screw
23	13650-49X00	Sensor, Water Temperature
24	09168-12017	Gasket

GSX-R750K8 E03 E28\_003  
 CYLINDER HEAD

**FIG.4**




**CRANKCASE**

Ref No	Part No	Description
1	11301-38860	Crankcase Set
2	11319-33E50	. Pin
3	01547-0635A	. Bolt
4	01547-0665A	. Bolt
5	01550-0850A	. Bolt
6	01550-0860A	. Bolt
7	01550-0875A	. Bolt
8	09103-08097	. Bolt (8x105)
9	09103-09012	. Bolt (9x95)
10	09103-09014	. Bolt (9x80)
11	09106-08184	. Bolt (8x55)
12	09103-08170	. Bolt (8x55)
13	01547-0630A	. Bolt
14	01547-0645A	. Bolt
15	01550-0865A	. Bolt
16	01550-0885A	. Bolt
17	09168-06023	. Gasket (5.8x13x1.2)
18	09168-08016	. Gasket (8.2x14x1)
19	09168-10031	. Gasket (10.2x20x2.3)
20	16591-06B01	. Union, Oil Filter Stand
21	09280-00043	. O Ring, Drive Shaft Bearing Cover (d:1.9,id:99.5)
22	09139-06151	. Bolt, Drive Shaft Bearing Cover (6x20)
23	12228-17E00-0D0	. Bearing, Thrust Rh (green)
24	12228-17E00-0A0	. Bearing, Thrust Lh (red)
24	12228-17E00-0B0	. Bearing, Thrust Lh (black)
24	12228-17E00-0C0	. Bearing, Thrust Lh (blue)
24	12228-17E00-0D0	. Bearing, Thrust Lh (green)
24	12228-17E00-0E0	. Bearing, Thrust Lh (yellow)
24	12228-17E00-0F0	. Bearing, Thrust Lh (white)
25	11329-02F00	Jet, Oil Gallery
26	11390-35F00	Jet, Piston Cooling
27	09280-04004	O Ring (d:1.2,id:4.0)
28	09106-06075	Bolt, Piston Cooling
29	09241-26004	Plug, Balancer Shaft Hole
30	09246-05006	Plug, Oil Gallery
31	09248-12004	Plug, Oil Gallery
32	09248-16013	Plug, Oil Gallery
33	09168-12002	Gasket, Oil Gallery
34	09168-16002	Gasket, Oil Gallery
35	09280-08012	O Ring (d:1.9,id:7.8)
36	09493-28012	Jet
37	11971-33210	Lens, Oil Level
38	08331-4130A	Circlip
39	11371-01H00	Cover, Breather
40	11484-01H00	Gasket, Breather Cover
41	13150-01H00	Valve Assy, Breather Reed
42	11372-01H00	Cover, Valve
43	01547-0616A	Bolt
44	01547-0630A	Bolt
45	09103-10041	Bolt (10x215)
46	09103-10145	Bolt (10x205)
47	09159-10115	Nut
48	09106-10069	Bolt, Eng Mtg (10x45)
49	09106-10070	Bolt, Eng Mtg (10x55)

GSX-R750K8 E03 E28\_004  
 CRANKCASE


**FIG.4**



Ref No	Part No	Description
50	11322-01H00	Plate, Lower
51	09103-06188	Bolt

GSX-R750K8 E03 E28\_004  
 CRANKCASE


**FIG.5**



Ref No	Part No	Description
1	11341-37H00	Cover, Clutch
2	11482-01H00	Gasket, Clutch Cover
3	11342-41G10	Cap, Clutch Release Adjust
4	09280-54001	O Ring (d:2.4,id:52.6)
5	04211-09189	Pin
6	09168-06023	Gasket (5.8x13x1.2)
7	09103-06213	Bolt
8	11971-25D00	Plug, Engine Oil Filter
9	09280-17003	O Ring (d:3.1,id:16.8)
10	09259-36021	Plug, Shaft Hole
11	09280-33004	O Ring (d:3.1,id:32.7)
12	11351-01H02	Cover, Generator
13	11352-01H00	Cap, Starter Idle Gear
14	11483-01H00	Gasket
15	09280-71008	O Ring
16	04211-09149	Pin
17	09103-06212	Bolt
18	09103-06238	Bolt
19	09103-06274	Bolt
20	09103-06222	Plug, Oil Gallery
21	09168-06018	Gasket
22	11361-01H00	Cover, Engine Sprocket
23	04211-09129	Pin
24	09103-06224	Bolt (6x45)
25	09103-06239	Bolt (6x65)
26	09103-06257	Bolt (6x75)

GSX-R750K8 E03 E28\_005  
 CRANKCASE COVER

**FIG.6**




Ref No	Part No	Description
1	11511-01H00	Pan, Oil
2	11489-01H00	Gasket
3	01547-0625A	Bolt
4	09103-06204	Bolt (6x30)
5	09168-06023	Gasket (5.8x13x1.2)
6	09247-14036	Plug, Oil Drain
7	09168-14002	Gasket
8	37820-33D10	Switch, Oil Pressure
9	37822-33D00	• Bolt
10	16400-01H00	Pump Assy, Oil
11	01547-0635A	Bolt
12	09280-15007	O Ring
13	04211-09149	Pin
14	16321-01H00	Sprocket, Drive
15	09181-10158	Washer
16	16331-01H00	Sprocket, Driven
17	09103-06285	Bolt (6x12)
18	16310-01H00	Chain, Oil Pump Drive
19	16440-24F00	Valve Assy, Oil Relief
20	09280-13004	• O Ring (d:1.9,id:13.0)
21	16520-01H00	Strainer, Engine Oil No.1
22	09280-25004	O Ring

GSX-R750K8 E03 E28\_006  
 OIL PAN/OIL PUMP




**FIG.8**




Ref No	Part No	Description
1	12611-01H00	Gear, Starter Idle No.1
2	12612-01H00	Gear, Starter Idle No.2
3	09206-12007	Pin
4	09263-12023	Bearing (12x16x15.8)
5	09181-12167	Washer, Starter Idle No.1
6	09164-12021	Washer
7	12600-01810	Clutch Set, Starter
8	09139-06153	Bolt (6x30)

**FIG.9**



Ref No	Part No	Description	
1	12654-02H00	Balancer, Crank	
2	12666-01H00	Gear, Crank Balancer	
3	12686-40F00	Damper, Crank Balancer Gear	
4	12229-40F50-0A0	Bearing, Crank Balancer	(green)
4	12229-40F50-0B0	Bearing, Crank Balancer	(black)
4	12229-40F50-0C0	Bearing, Crank Balancer	(brown)
5	09181-23002	Washer	


**FIG.10**



Ref No	Part No	Description
1	12710-38H00	Camshaft, Intake
2	12720-38H00	Camshaft, Exhaust
3	12891-17E00	Tappet, Intake
4	12891-35F00	Tappet, Exhaust
5	12911-02H00	Valve, Intake
6	12912-02H00	Valve, Exhaust
7	12921-02H00	Spring, Valve
8	12931-29G00	Retainer, Valve Spring
9	12933-29G00	Seat, Valve Spring
10	12932-32C00	Cotter, Valve
11	09289-04002	Oil Seal
12	12892-05C00-120	Shim, Tappet (t:1.20)
12	12892-05C00-125	Shim, Tappet (t:1.25)
12	12892-05C00-130	Shim, Tappet (t:1.30)
12	12892-05C00-135	Shim, Tappet (t:1.35)
12	12892-05C00-140	Shim, Tappet (t:1.40)
12	12892-05C00-145	Shim, Tappet (t:1.45)
12	12892-05C00-150	Shim, Tappet (t:1.50)
12	12892-05C00-155	Shim, Tappet (t:1.55)
12	12892-05C00-160	Shim, Tappet (t:1.60)
12	12892-05C00-165	Shim, Tappet (t:1.65)
12	12892-05C00-170	Shim, Tappet (t:1.70)
12	12892-05C00-175	Shim, Tappet (t:1.75)
12	12892-05C00-180	Shim, Tappet (t:1.80)
12	12892-05C00-185	Shim, Tappet (t:1.85)
12	12892-05C00-190	Shim, Tappet (t:1.90)
12	12892-05C00-195	Shim, Tappet (t:1.95)
12	12892-05C00-200	Shim, Tappet (t:2.00)
12	12892-05C00-205	Shim, Tappet (t:2.05)
12	12892-05C00-210	Shim, Tappet (t:2.10)
12	12892-05C00-215	Shim, Tappet (t:2.15)
12	12892-05C00-220	Shim, Tappet (t:2.20)
13	12800-05830	Shim Set, Tappet T:1.20, 1.25...2.95, 3.00
14	99000-69491	• . Case, Tappet Shim


(5pcs.each) & No.14

**FIG.11**




Ref No	Part No	Description
1	12760-39F00	Chain, Cam Shaft Drive
2	12771-37H00	Guide, Cam Chain No.1
3	12782-29G00	Guide, Cam Chain No.2
4	12811-02H00	Tensioner, Cam Chain
5	12812-31G00	Bolt
6	12830-37H00	Adjuster Assy, Tensioner
7	12837-02H00	Gasket, Adjuster
8	07130-0625B	Bolt

**FIG.12**



Ref No	Part No	Description
1	13406-38H00	Body Assy, Throttle
1	13406-38H10	Body Assy, Throttle
2	13426-29G00	. Torsion Spring
3	13420-37H00	. Lever Assy
4	13427-29G00	. Packing
5	13424-29G00	. E Ring
6	13295-29900	. O Ring
7	13606-47A00	. Washer
8	13268-48700	. Spring, Throttle Screw
9	13269-33E00	. Screw
10	13580-29G00	. Sensor Assy
11	13580-40F30	. Sensor Assy
12	13575-29G00	. O Ring
13	13605-02F00	. Screw
14	18117-37H00	. Motor Assy
15	13605-37H00	. Screw
16	13679-37H00	. O Ring

**FIG.13**




Ref No	Part No	Description
1	13473-37H00	Delivery Pipe Assy
2	13473-37H10	Delivery Pipe Assy
3	13473-29G00	Nipple Assy
4	13602-29G00	Packing
5	13601-29G00	Screw
6	15721-29G00	O Ring
7	15710-37H00	Injector Assy
8	15717-16G00	• O Ring
9	15710-37H10	Injector Assy
10	15717-16G00	• O Ring
11	15722-29G00	Seal
12	13698-37H00	Hose
13	13698-37H10	Hose
14	13683-37H00	Hose
15	13683-37H10	Hose
16	13683-04F50	Hose
17	13471-18H00	Nipple
18	13683-37H20	Hose
19	13683-37H30	Hose
20	13685-29G00	Nipple
21	13671-29G00	Clip
22	13680-37H00	Hose
23	13685-48B00	Nipple
24	13671-06A10	Clip
25	13680-37H10	Hose
26	09401-10411	Clip
27	18117-82K00	Valve, Canister Purge
28	13165-37H00	Bracket
29	09180-06310	Spacer
30	09320-10055	Cushion
31	09116-06212	Bolt
32	08316-1006A	Nut

GSX-R750K8 E03 E28\_013  
 THROTTLE BODY HOSE/JOINT




**FIG.15**



Ref No	Part No	Description
1	14100-38H00	Pipe, Exhaust
2	14181-46E00	Gasket
3	07130-0825A	Bolt
4	14310-38H00-H01	Body, Muffler
5	14771-42F10	Connector
6	14459-42F60	Clamp
7	14458-06H00	Spacer
8	09103-08392	Bolt
9	09118-08152-A05	Bolt
10	09180-08152-A05	Spacer
11	09320-12077	Cushion
12	14770-01H00	Bracket
13	07120-0816A	Bolt
14	09103-08358	Bolt
15	09160-08142	Washer
16	09180-08152	Spacer
17	09320-12048	Cushion
18	08361-2508A	Nut
19	14780-37H00	Cover, Muffler
20	09139-06078	Screw
21	09320-08066	Cushion
22	11276-37H00	Cable, Exh Valve No.1
23	11277-37H00	Cable, Exh Valve No.2
24	14250-01H00	Bracket
25	08316-1006A	Nut
26	11269-18G00	Pulley, Controller
27	07120-0516A	Bolt
28	18213-18H00	Sensor, Oxygen
29	09404-06429	Clamp

GSX-R750K8 E03 E28\_015  
 MUFFLER


**FIG.16**



Ref No	Part No	Description
1	16600-01H00	Cooler Assy, Oil
2	09280-64003	O Ring (d:3.1,id:63.9)
3	09106-06099	Bolt
4	16461-01H00	Hose, Inlet
5	16471-01H10	Hose, Outlet
6	09402-22512	Clamp
7	16510-03G00-X07	Filter Assy, Engine Oil

GSX-R750K8 E03 E28\_016  
 OIL COOLER


**FIG.17**



Ref No	Part No	Description
1	15100-37H00	Pump Assy, Fuel
2	15111-27G00	. Cup, Reservoir
3	15112-05H00	. Joint
4	15113-05H00	. O Ring
5	15113-35F00	. O Ring
6	15114-27G00	. Wire, Earth
7	15115-27G00	. Wire, Lead
8	15116-10F00	. Screw
9	15119-23H00	. Saddle, Edge
10	15181-37H00	. Bracket, Gauge
11	15420-05H00	. Strainer
12	15610-27G00	. Regulator
13	34810-37H00	. Gauge Assy, Fuel Level
14	15201-35F00	O-ring
15	07120-0612A	Bolt
16	15810-37H00	Hose, Fuel


GSX-R750K8 E03 E28\_017  
 FUEL PUMP

**FIG.18**




Ref No	Part No	Description
1	17400-01H10	Pump Assy, Water
2	17491-01H00	• Impeller
3	17470-02F10	• Seal, Mechanical
4	17461-01H00	• Seal, Oil
5	17432-07G00	• Washer
6	17511-01H00	• Shaft
7	17418-33400	• O Ring
8	17435-33400	• O Ring
9	02112-0616A	• Screw
10	09168-06016	• Gasket (6x15x2.2)
11	09164-06006	• Washer
12	09100-06099	• Bolt (6x13)
13	17415-20920	• Bolt, Drain
14	09168-08016	• Washer
15	01547-0635A	Bolt

**FIG.19**




Ref No	Part No	Description
1	17710-01H10	Radiator Assy, Water
2	17730-14G00	Cap
3	09118-06097	Bolt
4	09180-06290	Spacer
5	09320-10051	Cushion
6	17750-01H00	Bracket
7	01550-0612A	Bolt
8	17800-01H00	Fan Assy, Radiator
9	17711-14G00	Bolt
10	17802-14F00	Nut
11	17771-37H00	Shield, Heat

**FIG.20**




Ref No	Part No	Description
1	17851-01H00	Hose, Radiator Inlet
2	17852-01H00	Hose, Radiator Outlet
3	17853-01H00	Hose, Cylinder Inlet
4	09402-38512	Clamp
5	17861-01H00	Connector, Cylinder Inlet
6	17863-01H00	O-ring
7	01547-0620A	Bolt
8	17854-01H10	Hose, Water Bypass
9	09401-12409	Clip
10	09401-14403	Clip
11	17910-37H00	Tank Assy, Reservoir
12	17931-02FA0	• Cap
13	09111-06085	Bolt
14	17981-18G00	Hose
15	17982-37H00	Hose
16	09401-08411	Clip
17	09404-06429	Clamp
18	17661-37H00	Cover, Thermostat
19	17662-01H00	Connector
20	17663-01H00	O-ring
21	17670-76G00	Thermostat, Water
22	01547-0620A	Bolt
23	01550-0625A	Bolt

**FIG.21**



Ref No	Part No	Description
1	18450-01H00	Valve Assy, 2nd Air Reed
2	18610-01H00	Bracket, 2nd Air Valve
3	01550-0616A	Bolt
4	18510-29G30	Valve Assy, Air Cut
5	18711-37H00	Hose, 2nd Air Cleaner
6	18461-01H00	Hose, 2nd Air Valve, R
7	18471-01H00	Hose, 2nd Air Valve, L
8	09401-17201	Clip
9	09401-17401	Clip


**FIG.22**



Ref No	Part No	Description
1	21200-02840	Gear Assy, Primary Driven
2	21253-01H10	Spacer, Oil Pump Drive
3	09160-25073	Washer (25x54x2.4)
4	09263-35015	Bearing (35x40x26.8)
5	09263-35045	Bearing (35x40x12.8)
6	21410-41G30	Hub, Clutch Sleeve
7	21482-41G00	Bolt, Clutch Spring
8	21413-01H00	Spring, Clutch
9	21441-36F30	Plate, Clutch Drive No.1
10	21441-36F10	Plate, Clutch Drive No.2
11	21442-41G00	Plate, Clutch Drive No.3
12	21451-41G10	Plate, Clutch Driven No.1
13	21451-41G30	Plate, Clutch Driven No.2
14	21462-41G00	Disc, Clutch Pressure
15	21471-41G00	Seat, Wave Washer
16	21472-41G10	Washer, Clutch Plate Wave
17	21611-41G30	Cam, Clutch Drive
18	21612-41G10	Cam, Clutch Driven
19	21621-41G00	Washer, Cam Reaction Wave
20	21624-41G00	Washer, Cam Reaction Seat
21	21622-41G00	Lifter, Clutch Pressure Disc
22	21623-41G00	Nut, Cl Press Disc
23	09181-08139	Washer (8x14x1.0)
24	09159-24010	Nut, Clutch Sleeve Hub
25	09160-25056	Washer, Clutch Sleeve Thr
26	09164-24006	Washer, Clutch Wave
27	09160-25077	Washer, Sleeve Hub Nut
28	23110-38B00	Rod, Clutch Push Rh
29	23111-35F00	Rod, Clutch Push Lh
30	23121-41G00	Piece, Clutch Push
31	23122-41G00	Camshaft, Clutch Release
32	23123-41G00	Cap, Clutch Push Rod
33	23125-41G00	Spring, Clutch Release
34	23271-41G20	Arm, Clutch Release
35	09103-06223	Bolt, Cl Release
36	09134-06015	Screw, Clutch Push
37	09160-10020	Washer, Clutch Push
38	09160-15045	Washer, Clutch Push
39	09263-10014	Bearing, Cl Cam Shaft
40	09263-12027	Bearing, Cl Rise Cam
41	09263-15003	Bearing, Cl Push Piece
42	09282-10012	Seal, Cl Rise Cam Shaft
43	09285-06011	Seal, Clutch Push Rod
44	09285-10004	Seal, Clutch Push Rod
45	08310-0006A	Nut, Clutch Release
46	24741-01H00	Retainer, Cl Push Rod
47	09139-06153	Screw, Push Rod


GSX-R750K8 E03 E28\_022  
 CLUTCH

**FIG.23**



Ref No	Part No	Description
1	24120-01H00	Shaft, Counter (nt:14)
2	24221-35F00	Gear, 2nd Drive (nt:19)
3	24231-01H00	Gear, 3rd & 4th (nt:21/24)
4	24251-01H00	Gear, 5th Drive (nt:23)
5	24252-35F00	Bush 5th Drive Gear
6	24261-01H01	Gear, 6th Drive (nt:24)
7	24262-35F00	Bush, 6th Drive Gear
8	09167-27001	Washer, 6th Drive
9	09160-27008	Washer, 5th Drive
10	09263-20087	Bearing, Cntr Lh
11	09262-25150	Bearing, Cntr Rh
12	09285-20006	Seal, Oil (20x31.2x2.7)
13	09380-27006	Circlip, 5th Drive
14	09380-27006	Circlip, 6th Drive
15	09380-27004	Circlip, 2nd Drive
16	09390-62012	C Ring, Cntr Rh
17	09261-06003	Pin, Counter Shaft, Lh
18	24131-01H01	Shaft, Drive
19	24311-35F20	Gear, 1st Driven (nt:39)
20	24321-35F11	Gear, 2nd Driven (nt:39)
21	24322-35F00	Bush, 2nd Driven
22	24331-40F30	Gear, 3rd Driven (nt:36)
23	24262-17E01	Bush, 3rd Driven
24	24262-17E01	Bush, 4th Driven Gear
25	24333-02F00	Washer, 3rd & 4th Driven
26	24341-40F20	Gear, 4th Driven (nt:36)
27	24351-01H20	Gear, 5th Driven (nt:31)
28	24361-01H00	Gear, 6th Driven (nt:26)
29	09262-28045	Bearing, Drive Shaft, Lh
30	09283-42018	Seal, Drive Shaft, Oil
31	09300-22008	Bush, 1st Driven Gear
32	09380-27006	Circlip, 2nd Driven Gear
33	09380-27006	Circlip, 3rd Driven Gear
34	09380-27006	Circlip, 4th Driven Gear
35	09181-22223	Washer, 1st Driven Lh
36	09160-27008	Washer, 2nd Driven
37	27510-20A20	Sprocket, Engine (nt:17)
38	27531-01H00	Spacer, Engine Sprocket
39	27600-33E40-116	Chain Assy (rk Gb525r0z5y)
40	27620-33E40	Joint Set
41	09159-20004	Nut, Engine Sprocket
42	09160-25009	Washer (25x41x3)
43	09280-24010	O Ring (d:2.4,id:23.7)
44	24751-01H10	Retainer, Drive Shaft, L
45	24771-01810	Housing, Drive Shaft Set
46	09139-06159	Screw, Drive Shaft (6x20)
47	09139-06159	Screw, Retainer (6x20)
48	09280-68009	O Ring


**FIG.24**



Ref No	Part No	Description
1	25211-01H01	Fork, Gear Shift, No.1
2	25231-01H01	Fork, Gear Shift, No.3
3	25411-35F00	Shaft, Gear Shift Fork
4	25712-37H00	Plug, Gear Shift Fork
5	25310-01H00	Cam, Gear Shift
6	04221-04089	• Pin, Shift Cam
7	25312-42F01	Bolt, Gear Shift Cam
8	25381-13E30	Plate, Gear Shift Cam
9	09136-06147	Screw, Gear Shift Cam
10	09262-25006	Bearing, Gear Shift Cam
11	09263-25018	Bearing, Gear Shift
12	25350-06G00	Stopper, Shift Cam
13	25355-01H00	Spring, Shift Cam Stopper
14	25357-01H00	Bolt, Shift Cam
15	25358-01H00	Spacer, Cam Stopper
16	25510-01H00	Shaft, Gear Shift
17	25512-06G10	Plate, Gear Shift Cam
18	25519-01H00	Washer, Gear Shift Shaft
19	25518-01H00	Spring, Gear Shift Return
20	25671-01011	Stopper, Gear Shift Arm
21	09126-06014	Bolt, Gear Shift End
22	09160-14016	Washer, Gear Shaft, Lh
23	09263-14027	Bearing, Gear Shaft
24	09283-14006	Seal, Gear Shaft
25	09444-20001	Spring, Shift Return
26	09181-14167	Washer, Gear Shaft
27	08331-31146	Circlip, Gear Shaft
28	25520-01H00	Arm, Gear Shift Link
29	25525-01H00	Rod, Gear Shift Link
30	25600-01H00	Lever Assy, Gear Shift
31	25652-20C00	• Rubber, Gear Pedal
32	25617-03F10	Shaft, Gear Shift Lever
33	25681-01H00	Bracket, Gear Shift Lever
34	09106-08167	Bolt, Gear Bracket
35	09140-06025	Nut, Link Rod, L
36	09160-12011	Washer, Gear Shift Lever
37	01500-0625A	Bolt, Gear Shift Arm
38	08310-00067	Nut, Gear Shift Rod
39	08331-3112A	Circlip
40	37730-01H01	Sensor Assy, Gear Position
41	09280-26005	O Ring, Gear Shift
42	09106-05023	Bolt, Gear Shift Sw

GSX-R750K8 E03 E28\_024  
 GEAR SHIFTING


**FIG.25**




Ref No	Part No	Description
1	31100-37H00	Motor Assy, Starting
2	31130-13E00	• . Brush Terminal Set
3	31132-13E00	• . Brush Holder Set
4	31135-31300	•• .. Spring, Brush
5	31143-49040	• . O Ring
6	31264-13E00	• . O Ring
7	31170-19B10	• . Washer Set
8	09280-24003	• . O Ring (d:3.0,id:24.5)
9	31280-15D10	• . Set Bolt
10	31156-13E00	•• .. O Ring
11	09103-06212	Bolt (6x25)
12	08361-3506A	Nut

**FIG.26**

Ref No	Part No	Description
1	31402-01H10	Rotor Assy
2	31401-01H10	Stator Assy
3	32371-13E00	Clamp, Gen Lead
4	09103-12005	Bolt (12x23)
5	07130-0512A	Bolt, Gen Lead
6	07130-0620A	Bolt, Stator




**FIG.27**



Ref No	Part No	Description
1	33220-01H00	Sensor Assy, Cam Position
2	33110-01H00	Stator, Signal Generator
3	33115-33E00	Clamp, Signal Generator
4	02112-0510A	Screw, Clamp
5	02112-0510A	Screw, Stator
6	07130-0616A	Bolt, Cam Position


**FIG.28**



Ref No	Part No	Description
1	33610-02F01	Battery Assy (12v,10ah)
2	33652-16G00	Protector, Battery
3	33810-37H00	Wire, Starter Motor
4	33820-37H00	Wire, Battery Plus Lead
5	33624-16G00	• . Cap, Battery Plus
6	33860-37H00	Wire, Battery Minus


GSX-R750K8 E03 E28\_028  
 BATTERY

**FIG.29**




Ref No	Part No	Description
1	31800-41G00	Relay Assy, Starting Motor
2	09481-30501	• . Fuse (30a)
3	31861-38G00	• . Cover, Starter
4	09128-06013	Bolt (6x8)
5	32800-18H00	Rectifier Assy
6	32831-37H00	Bracket, Rect Ftg
7	32835-37H00	Mold, Rect Brkt
8	09180-06325	Spacer
9	09320-08066	Cushion, Rect Ftg Brkt
10	01550-0625A	Bolt, Rectifier
11	01550-0616A	Bolt, Brkt
12	09403-11315-A05	Clamp
13	08316-1006A	Nut, Rectifier
14	33410-38H00	Coil Assy, Ignition
15	32920-38H10	Control Unit, Fi
16	32920-38H20	Control Unit, Fi
17	33652-38A10	Cushion (20x90x2)
18	33960-27G00	Sensor Assy, Fuel Cut
19	33970-41G00	Actuator Assy, Exhaust Control
20	33971-37H00	Holder, Actr
21	09116-06103	Bolt, Actr (6x30)
22	01550-0616A	Bolt, Actr Holder
23	09116-06202	Bolt, Actr (6x25)

**FIG.30**




Ref No	Part No	Description
1	34120-38H20	Speed & Tachometer Assy
1	34120-38H30	Speed & Tachometer Assy
2	34150-01H20	Case, Upper
3	34124-39G00	• . Switch, Rubber
4	34111-01H00	Case, Lower
5	09132-03008	Screw (3x16)
6	34955-33E00	Cushion
7	09404-06429	Clamp (1:45)
8	34955-13E00	Cushion, Meter
9	34149-18G00	Screw
10	34981-38G00	Rotor, Speed
11	34990-35F00	Sensor, Speed
12	07120-0512A	Bolt, Speed Sensor
13	07130-0825B	Bolt, Speed Rotor

**FIG.31**




Ref No	Part No	Description
1	35100-37H30-999	Headlamp Assy
2	35179-01H00	. Cover, Socket
3	35179-37H00	. Cover, Back
4	35179-76F10	. Cover, Socket
5	44572-37H00	. Fastener, Fuel Tank
6	09320-09039	. Cushion
7	36118-37H00	. Socket & Lead
8	09471-12151	Bulb (12v60w,hb3,#9005)
9	09471-12210	Bulb (12v55w,h11)
10	09471-12216	Bulb (12v5w)
11	09136-05062	Screw, Headlamp
12	03541-0516B	Bolt, Headlamp
13	35950-14A10	Reflex Reflector Assy, Fr
14	09119-06109	Bolt
15	09160-08090	Washer (8.5x14x1.5)

**FIG.32**



Ref No	Part No	Description
1	35601-41G00	Lamp Assy, Front, R
1	35602-41G00	Lamp Assy, Front, L
2	35610-41G00	• . Lamp Unit, R
3	35630-41G00	• . Lamp Unit, L
4	35618-10G50	• . Socket & Cord, R
5	35638-10G50	• . Socket & Cord, L
6	09471-12186	• . Bulb (12v21w)
7	09132-04032	Screw (4x20)
8	33652-20C00	Tape, Front (50x50x5)
9	94443-21H00	Cushion, Front (20x5x0.4)
10	35603-21H00	Lamp Assy, Rear, R
10	35604-21H00	Lamp Assy, Rear, L
11	35652-21H00	• . Lens, R
12	35672-21H00	• . Lens, L
13	35653-21H00	• . Gasket
14	35658-41G00	• . Socket & Cord, R
15	35678-41G00	• . Socket & Cord, L
16	35716-07A30	• . Plate, Rear
17	09471-12186	• . Bulb (12v21w)
18	03211-0412A	• . Screw
19	03212-04169	• . Screw
20	09148-04021	Nut, Rear Turnsignal
21	03541-0412A	Screw, Rear
22	03541-0512A	Screw, Rear
23	38610-03F00	Relay Assy, Turnsignal
24	38621-37H00	Bracket, Relay
25	01550-0612A	Nut, Brkt


**FIG.33**



Ref No	Part No	Description
1	35710-37H30	Lamp Assy, Rear Combination
2	44572-13G10	. Fastener, Rear Comb
3	47912-37H00	. Fastener, Rear Comb
4	09106-05031	Screw (5x12)
5	09407-14407	Clamp (l:145)
6	35910-41G30	Lamp Assy, License
7	35912-41G00	. Lens
8	35913-41G00	. Gasket
9	35917-41G00	. Cover
10	09471-12140	. Bulb (12v5w,bf150-40160a)
11	09160-06077	Washer (6.5x20x1.2)
12	09180-06278	Spacer (6.5x9x33.3)
13	08316-1006A	Nut
14	09404-06429	Clamp (l:45)
15	35927-41G30	Bracket, License Plate
16	09160-06077	Washer (6.5x20x1.2)
17	02142-0616A	Screw, Brk
18	08316-1006A	Nut, Brk
19	35970-14A20	Reflector Assy, Rear Side
20	08316-1005A	Nut, Rear Side Rr

GSX-R750K8 E03 E28\_033  
 TAIL LAMP


**FIG.34**



Ref No	Part No	Description
1	36610-37H30	Harness, Wiring No.1
2	09481-10501	• . Fuse (10a)
3	09481-15501	• . Fuse (15a)
4	36618-18G00	• . Boot
5	33652-29F00	Protector, Harness (30x80x1)
6	36619-37H00	Guide, Wiring Harness
7	36620-37H00	Harness, Wiring No.2
8	36618-41G00	• . Cover, Speedometer
9	36854-37H00	Wire, Actuator Lead
10	13311-01H10	• . Boot
11	36855-37H00	Wire, Rear Comb
12	36857-37H00	Wire, Relay Lead
13	36920-37H00	Protector (10x25x0.13)
14	36920-45G00	Protector (20x50x2.0)
15	09403-06310	Clamp
16	09404-06429	Clamp (l:45)
17	09407-17403	Clamp (l:170)
18	09407-14403	Clamp (l:125)
19	01550-0612A	Bolt
20	36851-01H00	Wire, Oil Pressure Lead
21	37101-40820	Lock Set
21	37101-40840	Lock Set
22	37100-41G10	• . Lock Assy, Steering
23	09139-08016	Screw, Steering Lock
24	37740-45D00	Switch Assy, Stop Lamp
25	09443-06087	Spring
26	37840-35F10	Switch Assy, Side Stand
27	01550-0616A	Bolt
28	38500-37H00	Horn Assy
29	01550-0616A	Bolt
30	38740-24X50	Relay Assy, Fan Motor
31	38740-24X50	Relay Assy, Fuel Pump
32	38740-39G00	Relay Assy, Head Lamp
33	37146-41G00	Key, Blank


GSX-R750K8 E03 E28\_034  
 WIRING HARNESS

FIG.35




Ref No	Part No	Description
1	37200-21H01	Switch Assy, Handle, Rh
2	02112-0530A	• . Screw
3	37400-37H10	Switch Assy, Handle Lh
4	02112-0525A	• . Screw
5	02112-05453	• . Screw

**FIG.36**




Ref No	Part No	Description
1	41100-02H10-YAP	Frame (black)
2	41211-37H00-YUG	Rail, Seat Rh (black)
3	41221-37H00-YUG	Rail, Seat Lh (black)
4	41770-01H00	Bridge, Seat Rail Front
5	42740-37H00	Bridge, Seat Rail Center
6	42730-37H00	Bridge, Seat Rail Upper
7	42750-37H00	Bridge, Seat Rail Rear
8	09103-06285	Bolt
9	41233-18G20	Bolt, Seat Rail
10	43585-01H01	Plug, Tank Rail
11	41911-40F01	Spacer, Engine Mount
12	09106-08185	Bolt
13	41921-35F00	Bolt, Adjust
14	41922-18G00	Nut, Adjust

**FIG.37**



Ref No	Part No	Description
1	42310-40F40	Stand, Prop
2	09111-10058	Bolt, Prop Stand
3	12935-27A00	Washer
4	09159-10103	Nut
5	09443-14070	Spring, Inner
6	09443-19016	Spring, Outer
7	42330-01H00	Bracket, Prop Stand
8	09106-10064	Bolt
9	43110-41G00	Pedal, Brake
10	09443-11033	Spring
11	09352-11153-600	Tube (l:600->2)


**FIG.38**



Ref No	Part No	Description
1	43541-01H00	Bracket, Front Footrest No.1 Rh
2	43551-01H01	Bracket, Front Footrest No.1 Lh
3	09106-08186	Bolt
4	43511-01H01	Bracket, Front Footrest No.2 Rh
5	43521-01H00	Bracket, Front Footrest No.2 Lh
6	43516-37H00	Bar, Footrest Rh
7	43526-37H00	Bar, Footrest Lh
8	43531-41G00	Holder, Footrest Bar Rh
9	09106-10064	Bolt, Rh
10	09208-08010	Pin
11	09448-14037	Spring
12	08332-1106A	E Ring
13	43576-07D01	Bolt, Bank Sensor
14	43571-01H00	Guard, Footrest Rh
15	43576-41G00	Guard, Footrest Lh
16	43577-35F00	Screw, Lh
17	43600-37H00	Footrest Assy, Pillion Rh
18	43700-37H00	Footrest Assy, Pillion Lh
19	43611-37H00	. Bar, Rh
20	43621-37H00	. Bar, Lh
21	09208-08011	. Pin
22	09440-05005	. Spring
23	06111-07004	. Ball
24	43816-01H01	. Plate
25	08332-1106A	. E Ring
26	09106-08186	Bolt


GSX-R750K8 E03 E28\_038  
 FOOTREST

**FIG.39**



Ref No	Part No	Description
1	44100-37H00-019	Tank Assy, Fuel (black)
1	44100-37H00-YKY	Tank Assy, Fuel (blue)
1	44100-37H20-019	Tank Assy, Fuel (black)
1	44100-37H20-YKY	Tank Assy, Fuel (blue)
2	44200-16850	Cap Set, Fuel Tank
2	44200-16860	Cap Set, Fuel Tank
3	09106-05017	Screw
4	44191-37H00	Shield, Fuel Tank Heat
5	09139-06172	Screw, Bracket
6	44572-44G00	Fastener, Cover
7	09329-18001	Cushion, Bracket
8	44541-41G00	Cushion, Side
9	44276-21H00	Cushion, Tank Cover
10	44542-41G00	Cushion, Rear
11	44530-41G00	Bracket, Rear
12	44543-37H00	Screw, Bracket
13	09320-08071	Cushion
14	09106-06119	Bolt, Joint
15	44561-18G00	Spacer, Joint
16	44423-41G00	Hose, Drain
17	44424-38G00	Hose, Breather
18	09352-12163-600	Hose, Joint
19	09367-06002	3 Way
20	09352-50823-00B	Hose, Breather No.2
21	44574-35F00	Stay, Fuel Tank


**FIG.40**



Ref No	Part No	Description
1	44291-37H00-YKV	Cover, Fuel Tank Front (black)
1	44291-37H00-YKY	Cover, Fuel Tank Front (blue)
1	44291-37H00-YME	Cover, Fuel Tank Front (orange)
2	44277-37H00	Cushion, Upper
3	44278-37H00	Cushion, Side
4	68111-18G20	Emblem
5	09106-08156	Bolt, Front
6	09160-08130	Washer
7	09320-12053	Cushion
8	09180-08174	Spacer
9	44520-37H00	Brack, Front
10	09139-05078	Screw
11	09320-08021	Cushion
12	09148-05052	Nut




**FIG.41**




Ref No	Part No	Description
1	44434-37H00	Hose, Tank & Valve
2	09401-11413	Clip
3	44240-17C00	Valve, Breather
4	44890-18G00	Plate, Valve No.1
5	44894-24A00	. Cushion
6	09229-04038	Rivet
7	08322-0104A	Washer
8	44892-24A00	Plate, Valve No.2
9	44894-24A00	. Cushion
10	02142-0408A	Screw
11	44435-37H00	Hose, Canister
12	17210-15H00	Canister
13	44880-37H00	Bracket
14	09139-06139	Bolt
15	44883-37H00	Cushion, Canister
16	44436-37H00	Hose, Purge
17	09251-07003	Cap
18	09401-12404	Clip
19	07120-0620A	Bolt, Clamp
20	09180-06286	Spacer
21	09404-06435	Clamp, Hose
22	09407-18402	Clamp

**FIG.42**



Ref No	Part No	Description
1	47110-37H00-019	Cover, Frame Rh (black)
1	47110-37H00-YBD	Cover, Frame Rh (blue)
1	47110-37H00-YLF	Cover, Frame Rh (gray)
2	47210-37H00-019	Cover, Frame Lh (black)
2	47210-37H00-YBD	Cover, Frame Lh (blue)
2	47210-37H00-YLF	Cover, Frame Lh (gray)
3	09321-06026	. . Cushion
4	47112-37H00	. . Tape, Rh
5	47212-37H00	. . Tape, Lh
6	47114-37H00	. . Cushion
7	47115-37H00	. . Cushion
8	47113-37H00	Cushion, Front
9	09409-06328	Clip, Front
10	09409-06314-5PK	Clip, Rear
11	47310-37H00-019	Cover, Frame Center (black)
11	47310-37H00-YKY	Cover, Frame Center (blue)
11	47310-37H00-1PX	Cover, Frame Center (black)
12	68131-21H00-YU8	. . Emblem (gray)
12	68131-21H00-YBD	. . Emblem (white)
12	68131-21H00-YD8	. . Emblem (silver)
13	09321-10002	. . Cushion
14	44572-13G10	. . Fastener
15	09136-06056	Bolt, Center
16	47312-37H00	Cushion
17	09180-06283	Spacer
18	47910-37H00-019	Cover, Frame Rear (black)
18	47910-37H00-YKY	Cover, Frame Rear (blue)
19	47913-37H00	. . Cushion
20	47912-37H00	. . Fastener
21	47710-38H00-YKV	Cover, Frame Rear Rh (black)
21	47710-38H00-YKY	Cover, Frame Rear Rh (blue)
21	47710-38H00-YME	Cover, Frame Rear Rh (orange)
22	47810-38H00-YKV	Cover, Frame Rear Lh (black)
22	47810-38H00-YKY	Cover, Frame Rear Lh (blue)
22	47810-38H00-YME	Cover, Frame Rear Lh (orange)
23	68131-38H00-J7A	. . Emblem, "750"
23	68131-38H00-FND	. . Emblem, "750"
23	68131-38H00-CTY	. . Emblem, "750"
24	47712-37H00	. . Cushion, Cover Upper
25	47713-37H00	. . Cushion, Side
26	45516-01H00	. . Cushion, Rear
27	45517-16G00	. . Tape
28	09409-06328	Clip
29	03541-0512A	Screw


**FIG.43**



Ref No	Part No	Description
1	47410-37H00-019	Cover, Frame Side Rh (black)
1	47410-37H00-YBD	Cover, Frame Side Rh (white)
1	47410-37H00-YLF	Cover, Frame Side Rh (gray)
2	47411-37H00-019	• Cover, Upper Rh (black)
2	47411-37H00-YBD	• Cover, Upper Rh (white)
2	47411-37H00-YLF	• Cover, Upper Rh (gray)
3	47412-37H00	• Cushion, Front Rh
4	47413-37H00	• Cushion, Upper Rh
5	47415-37H00	• Cushion, Lower Rh
6	47416-37H00	• Cushion, Center
7	47510-37H00-019	Cover, Frame Side Lh (black)
7	47510-37H00-YBD	Cover, Frame Side Lh (white)
7	47510-37H00-YLF	Cover, Frame Side Lh (gray)
8	47511-37H00-019	• Cover, Upper Lh (black)
8	47511-37H00-YBD	• Cover, Upper Lh (white)
8	47511-37H00-YLF	• Cover, Upper Lh (gray)
9	47512-37H00	• Cushion, Front Lh
10	47513-37H00	• Cushion, Upper Lh
11	47515-37H00	• Cushion, Lower Lh
12	47416-37H00	• Cushion, Center
13	44894-24A00	Cushion, Middle
14	47412-21H00	Cushion, Upper


**FIG.44**

Ref No	Part No	Description
1	53100-41G00-019	Fender, Front (black)
2	09139-06144	Screw, Front
3	09139-06171	Screw, Rear



GSX-R750K8 E03 E28\_044  
FRONT FENDER



**FIG.45**



Ref No	Part No	Description
1	56111-01H10	Handlebar, Rh
2	56151-01H10	Handlebar, Lh
3	56131-29G00	Cap
4	09106-08185	Bolt
5	56200-41822	Balancer Set, Handlebar
6	02122-0640B	• . Screw
7	09160-06131	• . Washer
8	56272-10G00	• . Expander
9	56273-10G10	• . Nut
10	56500-41G21	Mirror Assy, Rear View Rh
11	56600-41G21	Mirror Assy, Rear View Lh
12	94575-37H00	Cushion, Rh
13	94576-37H00	Cushion, Lh
14	56619-41G01	Nut
15	58200-37H00	Cable Assy, Clutch
16	58621-37H00	Guide, Clutch Cable
17	01547-0612A	Bolt, Clutch Guide
18	09407-17403	Clamp
19	58300-37H00	Cable Assy, Throttle No.1
20	58300-37H10	Cable Assy, Throttle No.2
21	02142-0510B	Screw, Case
22	58622-37H00	Guide, Throttle
23	01550-0520A	Bolt


GSX-R750K8 E03 E28\_045  
 HANDLE BAR

**FIG.46**




Ref No	Part No	Description
1	57110-21H01	Grip, Throttle
2	57300-29G00	Lever Assy, Blake
3	57431-29G00	• Bolt, Pivot
4	57433-09F00	• Nut
5	57460-17C11	Switch Assy, Stop
6	57465-17C00	• Screw
7	57211-21H00	Grip, Lh
8	57500-41G10	Lever Assy, Clutch
9	57621-41G00	• Lever, Clutch
10	57431-41G00	• Bolt
11	57532-41G00	• Collar
12	08319-2106B	• Nut
13	57560-05A00	• Switch Assy, Clutch
14	02122-03208	• Screw
15	01547-0620B	• Bolt, Holder
16	57641-33E21	• Nut, Cable Adjuster
17	57644-33E00	• Spring
18	57642-33E00	• Screw, Spring

**FIG.47**




Ref No	Part No	Description
1	63111-37H00	Fender, Rear Upper
2	63112-37H00-019	Cover, Upper (black)
2	63112-37H00-YBD	Cover, Upper (white)
2	63112-37H00-YLF	Cover, Upper (gray)
3	09180-06268	Spacer
4	09320-09016	Cushion
5	63161-43E10	Bolt
6	47414-37H00	Bracket, Parts Holder
7	03541-0516A	Screw
8	09462-00034	Band, Tool
9	09800-21039	Tool Assy
10	63115-37H00	Cushion, Upper
11	33652-29100	Cushion, Front
12	63116-37H00	Cushion

**FIG.48**




Ref No	Part No	Description
1	63113-37H00	Fender, Rear Lower
2	63122-37H00	Plate, Rear Fender
3	09103-06282	Bolt
4	63170-37H00-YMC	Cover, Rear Rh (silver)
5	63180-37H00-YMC	Cover, Rear Lh (silver)
6	63121-37H00	Bracket, Rear Fender
7	09139-06108	Bolt, Bracket
8	09152-06024	Nut
9	03541-0616B	Screw, Rear
10	07120-0510B	Bolt, Rear Cover
11	63114-01H02	Fender, Lower
12	09103-06302	Bolt
13	08322-0106A	Washer, License Plate
14	94423-03H00	Cushion, Cover

**FIG.49**



Ref No	Part No	Description
1	94401-37H10-019	Body, Cowling (black)
1	94401-37H10-YKY	Body, Cowling (blue)
1	94401-37H10-1PX	Body, Cowling (black)
2	68641-19F00-YU8	• Emblem (gray)
2	68641-19F00-YBD	• Emblem (white)
2	68641-19F00-YD8	• Emblem (silver)
3	44572-37H00	• Fastener
4	92146-37H00	Cushion
5	94611-37H00	Windscreen
6	09125-05133	Screw, Front
7	09125-05134	Screw, Upper
8	09159-05019	Nut
9	94511-37H00	Brace, Cowling
10	01550-0845A	Bolt
11	08313-2008A	Nut
12	09320-08028	Cushion


**FIG.50**




Ref No	Part No	Description
1	94671-37H00-YKV	Cover, Intake Front (black)
2	94443-06G00	Tape
3	94402-37H00	Pipe, Intake Rh
4	94412-37H00	• . Net, Rh
5	94403-37H00	Pipe, Intake Lh
6	94413-37H00	• . Net, Lh
7	94423-01H00	Molding, Rh
8	94433-01H00	Molding, Lh
9	03541-0516B	Screw
10	09320-08028	Cushion
11	94672-37H00-YKV	Cover, Intake Side Rh (black)
11	94672-37H00-YBD	Cover, Intake Side Rh (white)
11	94672-37H00-YME	Cover, Intake Side Rh (orange)
12	94682-37H00-YKV	Cover, Intake Side Lh (black)
12	94682-37H00-YBD	Cover, Intake Side Lh (white)
12	94682-37H00-YME	Cover, Intake Side Lh (orange)
13	09148-05052	Nut
14	03541-0512B	Screw, Front
15	09132-05050	Screw, Center
16	94479-35F00	Clip, Rear
17	94443-06G00	Tape

**FIG.51**

Ref No	Part No	Description
1	94419-37H00	Cover, Body Cowl
2	09409-06314-5PK	Clip, Front (black)
3	09409-08308-5ES	Clip, Rear (black)
4	94461-37H00	Cowl, Cover Inner Rh
5	94462-37H00	Cowl, Cover Inner Lh
6	94458-01H00	Cover, Lower Bracket
7	63161-43E00	Bolt




**FIG.52**



Ref No	Part No	Description
1	94490-37H20-019	Cowling, Side Rh (black)
2	94440-37H20-019	Cowling, Side Lh (black)
3	68681-21H10-CTY	• . Emblem, "gsx" Rh
4	68691-21H10-CTY	• . Emblem, "gsx" Lh
5	68681-37HA0	• . Emblem, "r"
6	94490-38H00-YKY	Cowling, Side Rh (blue)
7	94440-38H00-YKY	Cowling, Side Lh (blue)
8	68685-38H00-FNH	• . Tape, Rh
9	68695-38H00-FNH	• . Tape, Lh
10	94490-38H10-019	Cowling, Side Rh (black)
11	94440-38H10-019	Cowling, Side Lh (black)
12	68685-38H10-FNM	• . Tape, Rh
13	68695-38H10-FNM	• . Tape, Lh
14	68681-37HA0	• . Emblem, "r"
15	94478-37H00	Cushion
16	09139-05077	Screw
17	94475-37H00-YKV	Cover, Under Cowl Rh (black)
17	94475-37H00-YBD	Cover, Under Cowl Rh (white)
17	94475-37H00-YLF	Cover, Under Cowl Rh (gray)
18	94485-37H00-YKV	Cover, Under Cowl Lh (black)
18	94485-37H00-YBD	Cover, Under Cowl Lh (white)
18	94485-37H00-YLF	Cover, Under Cowl Lh (gray)
19	09320-08028	Cushion, Side Cowl
20	03541-0516A	Screw
21	09320-06026	Cushion, Cowl Cover


GSX-R750K8 E03 E28\_052  
 SIDE COWLING

**FIG.53**




Ref No	Part No	Description
1	94470-37H00-019	Cowling, Under Rh (black)
1	94470-37H00-YKY	Cowling, Under Rh (blue)
1	94470-37H00-YME	Cowling, Under Rh (orange)
2	94480-37H00-019	Cowling, Under Lh (black)
2	94480-37H00-YKY	Cowling, Under Lh (blue)
2	94480-37H00-YME	Cowling, Under Lh (orange)
3	68181-33C20-YU8	• . Emblem (gray)
3	68181-33C20-YBD	• . Emblem (white)
3	68181-33C20-YKV	• . Emblem (black)
4	94472-37H00	Shield, Heat Rear Upper Rh
5	94477-37H00	Cushion
6	94472-37H10	Shield, Heat Rh
7	09139-05064	Screw, Rh
8	09320-09016	Cushion, Lh
9	09139-06126	Screw, Lh
10	09321-10018	Cushion
11	94498-37H00	Cowling, Under Center
12	94479-35F00	Clip
13	09403-14311	Clamp, Drain Hose

**FIG.54**



Ref No	Part No	Description
1	68319-29F00	Label, Warning
1	68319-29F10	Label, Warning
2	68922-29F00	Label, Screen
2	68922-29F30	Label, Screen
3	68353-26E02	Label, Notice
4	68387-37H00	Label, Routing
5	68332-38H10	Label, Tire Information
5	68332-38H00	Label, Tire Information
6	68613-24F00	Label, Steering
6	68613-18E00	Label, Steering
7	99011-38H50-03A	Manual, Owner's
7	99011-38H50-01A	Manual, Owner's
7	99011-38H50-01F	Manual, Owner's


**FIG.55**



Ref No	Part No	Description
1	45100-37H00-6BY	Seat Assy (black)
2	09321-10039	• . Cushion, Front
3	09321-10011	• . Cushion
4	45149-37H00	• . Cushion
5	09139-06065-XC0	Bolt, Seat
6	09180-06320	Washer, Seat
7	45300-37H00-6BY	Seat Assy, Pillion (black)
8	45180-37H00-6BY	• . Band Assy, Seat
9	08319-3106A	• . Nut
10	09160-06088	• . Washer
11	45290-18G00	• . Striker
12	45220-20A01	Bracket, Seat Support
13	02122-0630A	Screw, Rear
14	45280-13A01	Cable, Seat Lock
15	95700-14810	Lock Set, Seat
16	45289-11F00	Plate, Seat Lock Assy
17	45288-14F00	Guide, Seat Lock Cable


GSX-R750K8 E03 E28\_055  
 SEAT

**FIG.56**



Ref No	Part No	Description
1	45550-37H00-YKY	Box, Seat Tail (blue)
1	45550-37H00-019	Box, Seat Tail (black)
2	45290-37H00	• Striker
3	45213-42F00	•• Cushion
4	45552-37H00	• Bottom
5	09148-06018	• Nut
6	02142-0612A	• Screw
7	09160-06077	• Washer


**FIG.57**



Ref No	Part No	Description
1	51103-38H00	Damper Assy, Front Fork Rh
2	51104-38H00	Damper Assy, Front Fork Lh
3	51110-38H00	. Tube, Inner Rh
4	51120-38H00	. Tube, Inner Lh
5	51830-38H00	. Piece, Adjuster Lower
6	52110-38H00	. Rod, Damper
7	51821-01H00	. Push Rod
8	09280-03002	.. O Ring
9	51161-38H00	. Packing
10	51147-38H00	. Bolt
11	51166-01H10	. Bolt, Axle Holder
12	51171-38H00	. Spring
13	51176-01H10	. Spacer, Spring
14	51175-22D00	. Joint, Spring Upper
15	51131-38H00	. Tube, Outer
16	51152-01H10	. Bush, Guide
17	51168-01H00	. Spacer, Seal
18	51153-01H10	. Seal, Oil
19	51556-38B00	. Ring, Stopper
20	51173-01H00	. Seal, Dust
21	51189-01H00	. Bolt, Fork
22	51187-01H00	. O Ring, Fork Bolt

GSX-R750K8 E03 E28\_057  
 FRONT DAMPER


**FIG.58**



Ref No	Part No	Description
1	51410-01H00	Stem, Steering
2	09267-30010	• . Bearing (30x55x17)
3	51644-12C00	• . Seal, Stem Lower
4	51328-27E30	Bolt
5	51311-01H00	Head, Steering Stem
6	51147-01H00	Bolt
7	51354-01H00	Washer
8	51353-01H00	Nut
9	09267-30010	Bearing (30x55x17)
10	51643-41G10	Seal, Stem Upper Dust
11	51644-12C00	Seal, Upper Dust
12	51641-33E00	Washer, Stem
13	51631-33E00	Nut, Stem
14	51750-21H10	Damper Assy, Steering
15	09269-08003	• . Bearing (8x17.5x11)
16	09106-08130	Bolt
17	64339-14101	Seal, Dust
18	08319-3108A	Nut
19	68281-35F00	Emblem, "s"


GSX-R750K8 E03 E28\_058  
 STEERING STEM

**FIG.59**



Ref No	Part No	Description
1	54111-37H00-019	Wheel, Front (17m/cxmt3.50) (black)
1	54111-37H00-PLY	Wheel, Front (17m/cxmt3.50) (blue)
2	54731-35F10	Spacer, Hub Bearing
3	09262-25061	Bearing (25x52x15)
4	09285-32004	Seal (32x52x7)
5	54711-41G00	Axle, Front
6	54712-41G00	Bolt, Axle
7	54751-41G00	Spacer, Front Axle, R
8	59210-37H00	Disc, Front Brake
9	09106-06124	Bolt
10	55110-38H00	Tire, Front, 120/70 Zr17m/c (58w)(bridgestone)
11	43130-24A00	Valve Assy, Wheel Rim (tr412)
12	55411-22H00	Balancer, Wheel No.1
12	55412-22H00	Balancer, Wheel No.2
12	55413-22H00	Balancer, Wheel No.3


**FIG.60**



Ref No	Part No	Description
1	59100-41G30-999	Caliper Assy, Front Rh
1	59300-41G30-999	Caliper Assy, Front Lh
2	59100-41820	• . Piston Set
3	59100-41810	• . Seal Set, Piston
4	59141-41G00	• . Pin
5	59145-18G00	• . Bolt
6	59151-29G00	• . Spring, Pad
7	59121-18410	• . Bleeder
8	55156-66310	• . Cap
9	59100-29840	Pad & Shim Set
10	59171-41G00	• . Shim
11	59172-41G00	• . Shim
12	09103-10392	Bolt (10x30)
13	59151-41G00	Pin, Caliper

GSX-R750K8 E03 E28\_060  
 FRONT CALIPER


**FIG.61**



Ref No	Part No	Description
1	09360-10062	Bolt, Upper (10x1.25x22)
2	09360-10062	Bolt, Lh (10x1.25x22)
3	09360-10064	Bolt, Rh (10x1.25x36)
4	09161-10009	Washer
5	59480-37H00	Hose, Front Brake No.1
6	59240-37H00	Hose, Front Brake No.2
7	59260-37H00	Clamp, Brake Hose No.1
8	01547-0612A	Bolt
9	09403-16413	Clamp, Brake Hose No.2


GSX-R750K8 E03 E28\_061  
 FRONT BRAKE HOSE

**FIG.62**




Ref No	Part No	Description
1	59600-01H20	Cylinder Assy, Front Master
2	59600-01810	• Piston/cup Set
3	59666-29G00	•• Boot
4	69686-34200	• O Ring
5	59672-17C00	• Connector
6	69674-00B20	• Circlip
7	59673-17C00	• Cover, Dust
8	59671-36500	• Holder
9	59675-02FA0	• Bolt
10	59121-01A00	• Bleeder
11	59122-01A00	• Cap, Bleeder
12	59740-07D00	Tank Assy, Reservoir
13	59667-18441	• Diaphragm
14	59668-18441	• Plate
15	59669-07D00	• Cap
16	59743-17C00	Plate, Tank Cap
17	02142-0410A	Screw
18	09111-05004	Bolt
19	59751-01H00	Bracket, Reservoir Tank
20	01547-0612A	Bolt
21	09159-05048	Nut
22	59731-01H00	Hose, Reservoir Tank
23	59735-17C00	Clamp, Hose

**FIG.63**



Ref No	Part No	Description
1	61000-01H10-YAP	Swinging Arm Assy, Rear (black)
2	09263-27013	. Bearing, Pivot
3	61281-41G00	. Spacer, Center
4	61124-41G00	Plate, Bracket
5	09125-06073	Screw
6	61251-41G00	Spacer, Bearing
7	61211-01H00	Shaft, Pivot
8	09159-20006	Nut
9	61214-42E00	Nut, Pivot
10	61273-01H00	Buffer, Chain Touch Defense
11	09111-06072	Screw
12	61311-01H10	Case, Chain
13	09103-06289	Bolt
14	09409-08308-5ES	Clip (black)
15	61445-40F20	Adjuster, Chain Rh
16	61446-40F10	Adjuster, Chain Lh
17	09100-08287	Bolt (8x50)
18	08316-1008A	Nut


**FIG.64**



Ref No	Part No	Description	
1	62601-01850	Lever Set, Rear Cushion	
2	09263-17034	. Bearing, Front (17x24x26)	
3	09263-17037	. Bearing, Lower (17x24x25)	
4	09263-20074	. Bearing, Upper (20x27x32)	
5	62646-08G00	Spacer, Lower	
6	62621-42E20	Bolt, Lower	
7	09159-12056	Nut	
8	62317-27C10	Spacer, Upper	
9	62658-35F00	Bolt, Upper	
10	09159-12056	Nut	
11	62684-40A10	Spacer, Front	
12	62601-01870	Rod Set, Rear Cushion Lever	
13	09263-17037	. Bearing, Rod (17x24x25)	
14	62626-21H00	Spacer, Rod	
15	62621-21H00	Bolt, Rod	
16	09159-12056	Nut	
17	09160-12037	Washer	
18	62100-38H10-163	Absorber Assy, Rear Shock	(yellow)
18	62100-38H00-163	Absorber Assy, Rear Shock	(yellow)
19	09103-10143	Bolt, Upper (10x55)	
20	09159-10115	Nut	
21	09103-10143	Bolt, Lower (10x55)	
22	62993-35F00	Bracket, Absorber	
23	09159-20006	Nut	

GSX-R750K8 E03 E28\_064  
 REAR CUSHION LEVER

**FIG.65**




Ref No	Part No	Description
1	64111-37H00-019	Wheel, Rear (17m/cxmt5.50) (black)
1	64111-37H00-PLY	Wheel, Rear (17m/cxmt5.50) (blue)
2	64731-01H00	Spacer, Hub Bearing
3	09262-28043	Bearing (28x52x12)
4	09284-37001	Seal, Rr Wheel Bearing, R
5	69211-18G00	Disc, Rear Brake
6	09106-08160	Bolt
7	64711-49G00	Axle, Rear
8	09159-25003	Nut
9	09160-25070	Washer
10	64741-35F00	Spacer, Axle Rh
11	64751-35F00	Spacer, Axle Lh
12	64610-44G00	Drum, Rear Sprocket
13	64733-35F00	Retainer, Sprocket Drum
14	09262-32007	Bearing (32x65x17)
15	09285-39001	Seal (39x65x7)
16	64651-44G00	Absorber, Hub Shock
17	64511-39F00	Sprocket, Rear (nt:45)
18	08319-3110A	Nut
19	65110-38H00	Tire, Rear, 180/55 Zr17m/c (73w)(bridgestone)
20	43130-24A00	Valve Assy, Wheel Rim (tr412)
21	55411-22H00	Balancer, Wheel No.1
21	55412-22H00	Balancer, Wheel No.2
21	55413-22H00	Balancer, Wheel No.3


GSX-R750K8 E03 E28\_065  
 REAR WHEEL

Ref No	Part No	Description
1	69100-21H00-999	Caliper Assy, Rear
2	69100-01860	• Piston Set
3	69102-05880	•• Seal Set, Piston
4	69115-44G00	• Spring, Pad
5	69105-44G00	• Pin, Bolt
6	59112-44B00	• Boot, Axle
7	69182-44G00	• Bolt
8	69185-44G00	• Sleeve
9	69186-44G00	• Boot, Sleeve
10	69150-21H00	• Bracket
11	69116-44G00	• Retainer
12	59141-40F00	• Pin, Pad
13	59121-18410	• Bleeder
14	55156-66310	• Cap, Bleeder Plug
15	69101-44810	Pad Set

**FIG.66**



**FIG.67**



Ref No	Part No	Description
1	69600-01H20	Cylinder Assy, Rear Master
2	69600-34820	. Piston / Cap Set
3	69691-00A00	•• . Boot
4	69692-22H00	. Yoke
5	69670-01H00	. Rod, Push
6	69693-05A00	. Nut
7	69672-00B20	. Connector
8	69686-34200	. O Ring
9	69674-00B20	. Circlip
10	09139-06125	Bolt
11	69740-01H10	Tank Assy, Rear Reservoir
12	69667-01H00	. Diaphragm
13	69668-01H00	. Plate, Diaphragm
14	69669-01H00	. Cap
15	69689-01H00	. Screw
16	01547-0612A	Bolt, Reservoir Tank
17	69750-01H00	Bracket, Rr Reservoir Tank
18	01547-0612A	Bolt, Bracket
19	69730-01H10	Hose, Reservoir Tank
20	09401-12404	Clamp
21	09401-14410	Clip, Lower
22	69480-01H00	Hose, Rear Brake
23	09360-10062	Bolt, Brake Fluid
24	09161-10009	Washer (10x15x1.5)
25	09200-06068	Pin
26	08322-0106A	Washer
27	04111-2015A	Pin, Cotter
28	69268-01H00	Clamp, Rr Brake Hose
29	01547-0612A	Bolt
30	09403-17306	Guide, Rr Brake Hose